USG DUROCK™ BRAND INTERIOR AND EXTERIOR TAPES

PRODUCT FEATURES

For joint reinforcement of USG Durock® Brand Cement Board, USG Fiberock® Brand Underlayment and Tile Backerboard, USG Durock™ Brand Glass-Mat Tile Backerboard, and USG Durock™ Brand UltraLight Foam Tile Backerboard.

- Alkali-resistant glass-fiber construction
- Reinforces joints and corners of cement board in exterior substrate applications and interior tile or thin-brick applications
- Sizes for interior (2" wide) and exterior (4" wide) joint reinforcement

DESCRIPTION

USG Durock™ Brand Interior and Exterior Tapes are specially designed to reinforce the joints and corners of USG tile backerboard panels. The 2" USG Durock™ Interior Tape is used to reinforce corners and joints of USG tile backerboard panels. USG Durock™ Exterior Tape is 4" wide, and it is the required product for completely covering and reinforcing corners and joints of USG Durock® Cement Board when used as an exterior substrate. USG Durock™ Interior and Exterior Tapes are made of alkali-resistant glass-fiber mesh to provide a strong, long-lasting joint.

DIRECTIONS - INTERIOR

Applications of tile and thin brick finishes

For USG Durock® Cement Board. Following application of USG Durock® Cement Board, prefill joints between panels of USG Durock® Cement Board with tile-setting mortar or adhesive. Center USG Durock™ Interior Tape over all joints and corners and embed in mortar or adhesive. Do not overlap pieces of the tape. Level the joints. For small areas where the USG Durock® Cement Board will not be tiled, such as a board extending beyond the tiled area and abutting another surface, treat joints as follows; seal USG Durock® Cement Board with Type 1 ceramic tile adhesive (mix four parts adhesive with one part water). Embed USG Boral Sheetrock® Brand Joint Tape over joints and treat fasteners with USG Boral Sheetrock® Brand Durabond® 45 or 90 Setting-Type Joint Compound applied in a conventional manner. Flat trowel USG Boral Sheetrock® Brand Durabond Setting-Type Joint Compound over board to cover fasteners and fill voids to a smooth surface. Finish joints with at least two coats of USG Boral Sheetrock® Brand Ready-Mixed Joint Compound. Do not apply ready-mixed or setting-type joint compound over unsealed board.

For USG Fiberock® Brand Tile Backerboard in tiled areas. Embed USG Durock™ Interior Tape in latex modified mortar or latex-based Type I mastic over the joint. Use the same material as specified for tile setting.

For finishing USG Fiberock® Brand Underlayment joints. Prefill all underlayment joints with tile setting mortar or adhesive. Immediately embed USG Durock™ Interior Tape over the joints and strike joints flush. Additional fill coats may be required. Sand uneven panel joints.

For USG Durock™ Brand Glass-Mat Tile Backerboard in tiled areas. Prefill joints between panels of USG Durock® Glass-Mat Tile Backerboard with tile-setting mortar or adhesive. Center USG Durock™ Interior Tape over all joints and corners and embed in mortar or adhesive. Do not overlap pieces of the tape. Level the joints. For small areas where the USG Durock® Glass-Mat Tile Backerboard will not be tiled, such as a board extending beyond the tiled area and abutting another surface, treat joints as follows; seal USG Durock® Glass-Mat Tile Backerboard with Type 1 ceramic tile adhesive (mix four parts adhesive with one part water). Embed USG Sheetrock® Brand Joint Tape over joints and treat fasteners with USG Sheetrock® Brand Durabond® 45 or 90 Setting-Type Joint Compound applied in a conventional manner. Flat trowel USG Boral Sheetrock® Brand Durabond Setting-Type Joint Compound over board to cover fasteners and fill voids to a smooth surface. Finish joints with at least two coats of USG Boral Sheetrock® Brand Ready-Mixed Joint Compound. Do not apply ready mixed or setting-type joint compound over unsealed board.

For USG Durock™ Brand UltraLight Foam Tile Backerboard. For applications not requiring waterproofing, pre-fill joints with unmodified tile-setting mortar and then immediately embed USG Durock™ Brand Tile Backer Tape and level joints.

DIRECTIONS - EXTERIOR

Application of tile and thin-brick finishes

Following application of USG Durock® Cement Board, prefill joints with latex-modified portland cement mortar. Center USG Durock™ Exterior Tape over all joints and corners and embed in mortar. Do not overlap pieces of the tape. Level the joints.

Application of texture finishes

Following application of USG Durock® Cement Board, prefill joints with a suitable basecoat. Center USG Durock™ Exterior Tape over all joints and embed in basecoat. Do not overlap pieces of the tape. Level the joints.

PRODUCT DATA

USG Durock™ Interior and Exterior Tapes are made from alkali-resistant glass-fiber mesh.

Sizes and Packaging: USG Durock™ Interior Tape: Rolls, 2" x 50' and 2" x 250'. USG Durock™ Exterior Tape: Rolls, 4" x 150'.

Shelf Life: Up to 12 months under protected storage conditions. Rotate stock.

Availability and Cost: USG Durock™ Interior and Exterior Tapes are distributed throughout the United States. Contact a USG sales office or salesperson for additional information.

REFERENCES

For further health and safety instructions, refer to the Safety Data Sheet (SDS) for this product, available from your USG Boral sales office or **USGBoral.com**